



EasyClean

Film Processor Transport Roller Clean up Sheets

Now you can easily clean the transport rollers in your film processor without the use of hazardous chemicals and without removing the rolling pack from your processor.

EasyClean sheets are coated with proprietary moisture activated cleaning formula that actually attaches to and removes the chemical build up from the transport rollers.

- Clean crisp films every time
- No hazardous cleaning chemicals
- Eliminates film waste and retakes due to scratches or pick off
- Reduces processor down time needed to clean transport rollers

Instructions for using *EASYSLEEN* sheets

1. Send the EasyClean sheet through the processor just as you would a sheet of film. The first time with the glossy side down to clean the lower rollers.
2. When the EasyClean sheet exits the processor, turn the sheet so the leading edge is reversed. Then put the sheet through with the glossy side up to clean the upper rollers.
3. If it is inconvenient to wait for and retrieve the sheet, a second sheet may be put through immediately after the first with the glossy side up.
4. The two sheets used only one time in step 3 can be used a second time by reversing the procedure above.
5. You may discard the used EasyClean sheets the same way as used film.
6. We recommend that EasyClean be used before each shift or anytime the processor has been idle for over 4 hours. There is never any worry about cross contamination of chemicals when using EasyClean.

FOR BEST RESULTS, PLEASE STORE FLAT

For More Information to Place an Order

Tel: 1-888-577-5786 • Fax: 1-866-827-8555 • E-mail: rharris@azcoat.com